

Stemware Rack

Assembly Instructions



Tools Needed

- Drill
- Pencil

Install Tips

- Mounted under cabinet
- Assembly blocks may need to be removed

Instructions

Step 1:

Place SWR onto the bottom of a wine rack or cabinet

Step 2:

Screw

Step 3:

Load the wine glasses